Giant Cone Display Case

Part No. 76132
Revised June 1996

Instruction Manual

Model #8211



GOLD MEDAL®
FUNFOOD EQUIPMENT & SUPPLIES
Cincinnati, OH 45241-4807 USA

SAFETY PRECAUTIONS



⚠ DANGER

Machine must be properly grounded to prevent electrical shock to personnel.
Do NOT immerse the equipment in water.

Always unplug the equipment before cleaning or servicing.



⚠ WARNING

ALWAYS wear safety glasses when servicing this equipment.



⚠ WARNING

Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment. Make sure all machine switches are in the off position before plugging the equipment into the receptacle.



⚠ CAUTION

Do NOT allow direct contact with this equipment and the general public when used in food service locations. Only personnel that are trained and familiar with the equipment should operate the equipment. Carefully read all installation instructions before operation.



⚠ CAUTION

This machine is NOT to be operated by minors. Minors are classified as anyone under the age of 18.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.

CONE DISPLAY INSTRUCTIONS

Your new Giant Cone Display Case is shipped requiring some assembly. After removing the case from the corrugated carton, check thoroughly for any damage which may have occurred in transit. Claims should be filed immediately with the transportation company. Remove all cardboard packing, tape, and separate parts from the case.

INSTALLATION INSTRUCTIONS

The following parts have been shipped unassembled and separate:

Part Number	Description	Quantity
76112	Cone Decal Sign	1
75267	T-Bolt	1
47120	Lid Lift Knob	1
76150	Instr., Sugar Cone Decal	1

After removing the parts package, check to see if the T-Bolt and the Lid Lift Knob are present. If these parts are not present, contact our nearest distributor or Gold Medal Products immediately.

Open the door and place the T-Bolt through the hole in the plexiglass from inside the case, so the threads are outside the case. Next put the Lid Lift Knob on the threads and turn clockwise until tight. After finishing, wipe all exposed surfaces with a damp cloth to remove fingerprints, smears, etc. which may have occurred during unpacking, installation or handling.

DIMENSIONS

12 ⅜" (31,4 cm) Wide x 16 ½" (41,9 cm) Deep x 22 ¾" (57,8 cm) High

USAGE

Open the door fully and insert the holding tray provided, taking care to keep the tray centered inside the case. Finished cones may be easily stacked inside each other. This tray will hold twelve stacks of cones. Each stack will hold approximately seven cones. This number will vary according to type of cone.

LOCATION

Always pick a good location for your case so that the public can see the attractive display. A front counter is usually best. Putting the case on a back location will greatly diminish sales.

CARE AND CLEANING

The aluminum corner posts and stainless steel base are easy to keep clean. Usually a damp cloth will remove all dirt and grease spots. Never use abrasives on aluminum, stainless steel parts or plexiglass side panels. Also avoid solvent based cleaners on the side panels; the use of these products can damage the surfaces.

The polycarbonate top, plexiglass sides and doors should always be kept clean and sparkling as this invites customer attention and sales. "Joy" dish detergent or a similar mild detergent should be used with lukewarm water to clean these panels. Empty out and periodically clean the inside of the case using a damp cloth to remove bits of material which may have fallen to the bottom.

CONE DECAL SIGN

The cone decal sign (Part No. 76112) should be placed in the proper location as stated on the instruction sheet (Part No. 76150).

MAINTENANCE INSTRUCTIONS



⚠ CAUTION

THE FOLLOWING SECTIONS OF THIS MANUAL ARE INTENDED ONLY FOR QUALIFIED SERVICE PERSONNEL. THESE ARE NOT INTENDED FOR THE OPERATOR.



⚠ WARNING

Adequate eye protection must be used when servicing this equipment to prevent the possibility of injury.

ORDERING SPARE PARTS


1. Identify the desired part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity desired.
3. Please include your model name and machine serial number (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:

(513) 769-7676
Fax: (513) 769-8500
E-mail: goldme19@eos.net

CONE DISPLAY ASSEMBLY



PARTS LIST - CONE DISPLAY ASSEMBLY

Item No.	Part No.	Description	Quantity
1	49052	Screw w/ Washer Taptite	8
2	40021	Bottom Right Extrusion	1
3	76117	Lexan Top Cover	1
4	40039	Bottom Left Extrusion	2
5	47561	Magnetic Catch	1
6	76129	Door (Plexiglass)	1
7	75267	Tee Bolt	1
8	47120	Knob Lid Lift	1
9	74141	Screw #8-32 x $^{3}/_{8}$" RD HD PH	2
10	47702	Acorn Nut #8-32	2
11	49021	Hinge	2
12	76116	Bottom Pan Weld ASM	1
13	74142	Screw #8-32 x ¼" RD HD PH	4
14	76125	Left Rear Post, Cone Case	1
15	76118	12-Hole Cone Tray	1
16	87247	Bumper, Rub. Headed Screw	4
17	76146	Hex Nut #8-32 ESLOK	4
18	40013	Plexiglass Panel	2
19	40014	Side Glass (Plexiglass)	1
20	4005	Right Front Corner Post	3
ITEMS NOT SHOWN			
	40001	Shipping Carton	1
	76132	Manual Giant Cone Display	1
	76150	Instr. Sugar Cone Decal	1
	76112	Sign, Cone Baker	1

WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTIBILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term “Original Purchaser” as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-428-2676 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.

GOLD MEDAL PRODUCTS COMPANY
10700 Medallion Drive
Cincinnati, Ohio 45241-4807 USA